



# Einhell

## EXPERT PLUS



Cordless Chain Sharpener

**GE-CS 18 Li-Solo**

**Item No.: 4499940**

Ident No.: 11015

Bar Code: 4006825613858

The Einhell cordless GE-CS 18 Li - Solo Chainsaw Sharpener restores the cutting edge to your chainsaw and saves you money. Why buy an expensive new chain when you can re-sharpen the one you already have? The chainsaw sharpener is ideal for quickly sharpening standard chains without excessive abrasion. A depth stop protects the chain from excessive material removal. The angle gauge and chain tensioner ensure the chain is ideally positioned for fast, precision grinding. The sharpener is supplied without a battery and charger which are available separately.

## Features & Benefits




- Depth stop
- Scala for precise setting of the grinding angle
- Clamping device
- Grinding wheel
- LED light
- Supplied without battery and charger (available separately)

## Technical Data

- Idle speed 6500 min<sup>-1</sup>

## Logistic Data

- Product weight (kg) 1.68
- Gross weight (kg) 2.2
- Dimensions single packaging 285 x 220 x 170 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 8.7 kg
- Dimensions export carton 590 x 460 x 190 mm
- Container quantity (20"/40"/40"HC) 1940 | 3880 | 4728



## Available as special accessories



Grinding Disc 4,5 mm  
Accessory garden technique  
Item No.: 4500071  
Bar Code: 4006825548853  
Einhell Grey



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory

Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Grinding Disc Kit 3,2 mm  
Chain Sharpener Accessory  
Item No.: 4500076  
Bar Code: 4006825548860  
Einhell Grey



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory




18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory

18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 3,0 Ah Power-X-Change  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 sanding <sup>1)</sup> (min.)
1.5 Ah	180
2.0 Ah	240
2.5 Ah	300
3.0 Ah	390
4.0 Ah	480
5.2 Ah	660
6.0 Ah	780

Test setup:

1) -