



Einhell

EXPERT PLUS



Cordless Lawn Mower

GE-CM 18/30 Li-Solo

Item No.: 3413157

Ident No.: 21021

Bar Code: 4006825631869

The Einhell GE-CM 18/30 Li - Solo cordless lawn mower is a powerful helper for maintaining lawns. Recommended for lawn areas up to 150m². For a long service life the mower has an Einhell brushless motor and a high-quality impact-resistant plastic housing. Practical features include the folding long handle for compact storage, the integrated carry handle for easy transportation and the 3-level axial cutting height adjustment facility. Large wheels exert less stress on the lawn. The system battery and charger are available separately.

Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- Brushless motor - more power and prolonged operation
- Axial cutting height adjustment, 3 levels
- Long handle folding - space saving storage
- Integrated carry-handle for easy transport
- Grass protecting, large wheels
- High quality, blow tough plastic housing
- Recommended for lawn areas up to 150 m²
- Recommendation for optimum results: 2,5Ah battery & higher
- Supplied without battery and charger (available separately)



Technical Data

- | | |
|-------------------------------|----------------------------|
| - Idle speed | 3300 min ⁻¹ |
| - Cutting width | 30 cm |
| - Cutting height adjustment | 3 30-70 mm axial wheel |
| - Capacity of catching device | 25 L |
| - Wheel diameter front | 140 mm |
| - Wheel diameter rear | 140 mm |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Gross weight (kg) | 10.43 |
| - Product weight (kg) | 8.87 |
| - Dimensions single packaging | 605 x 395 x 375 mm |
| - Pieces per export carton | 1 Pieces |
| - Gross weight export carton | 10.43 kg |
| - Dimensions export carton | 605 x 395 x 375 mm |
| - Container quantity (20"/40"/40"HC) | 312 642 749 |



Available as special accessories



Spare Blade GE-CM 18/30 Li
Lawn Mower Accessory
Item No.: 3404553
Bar Code: 4006825633092
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times



One Battery for All	lawn mowing ¹ (m ²)
1.5 Ah	30
2.0 Ah	70
2.5 Ah	100
3.0 Ah	150
4.0 Ah	210
5.2 Ah	270
6.0 Ah	300
8.0 Ah	420

For best performance select a battery with at least 2.5 Ah

Test setup:

1) lawn