



# Einhell

## PROFESSIONAL



Cordless Earth Auger

**GP-EA 18/150 Li BL-Solo**

**Item No.: 3437000**

Ident No.: 21010

Bar Code: 4006825659023

The cordless auger GP-EA 18/150 Li BL-Solo is a member of the Power X-Change family. The cordless device is delivered including the auger (80 cm length / 15 cm diameter). The durable brushless motor optimally converts the power to the thread. The auger is adjustable to 3 different modes: 1) Anti-clockwise to release the drill 2) Clockwise in ECO mode. Regular power setting for light drilling tasks in soft ground & 3) Clockwise in HIGH power mode. Maximum power setting for hard surfaces. The robust metal frame offers maximum stability. Battery and charger are not included. These are available separately. An 18 V PXC battery is also required for operation.

## Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Brushless motor - more power and longer runtime
- Metal frame - maximum stability and torsional stiffness
- 3 different modes: anticlockwise, clockwise: ECO & HIGH POWER
- Earth auger (80cm length / 15cm diameter) included in delivery
- Durable and robust gearbox integrated in aluminium housing
- Double handle with softgrip for ergonomic working
- Recommended for perfect results: 2,5Ah battery and bigger
- Supplied without battery and charger (available separately)

## Technical Data

- No-load speed 125 min<sup>-1</sup>
- Auger diameter 150 mm
- Length of drill 800 mm

## Logistic Data

- Product weight (kg) 6.01
- Gross weight (kg) 8.3
- Dimensions single packaging 1120 x 213 x 432 mm
- Pieces per export carton 2 Pieces
- Gross weight of export carton 19 kg
- Dimensions export carton 1420 x 450 x 235 mm
- Container quantities (20"/40"/40"HC) 384 | 760 | 892



## Available as special accessories



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



2x 5,2Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB  
Battery  
Item No.: 4511524  
Bar Code: 4006825656206  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



5,2Ah & 4A Fastcharger  
PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



Mortar Stirrer (Earth Auger)  
Earth Auger Accessory  
Item No.: 3437011  
Bar Code: 4006825659047  
Einhell Accessory



1m Extension (Earth Auger)  
Earth Auger Accessory  
Item No.: 3437012  
Bar Code: 4006825659054  
Einhell Accessory



120mm Earth Auger  
Earth Auger Accessory  
Item No.: 3437010  
Bar Code: 4006825659030  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

# Battery-Running-Times

<b>One Battery for All</b>	earth drilling <sup>1</sup> (pieces)
<b>1.5 Ah</b>	10
<b>2.0 Ah</b>	15
<b>2.5 Ah</b>	20
<b>3.0 Ah</b>	30
<b>4.0 Ah</b>	40
<b>5.2 Ah</b>	50
<b>6.0 Ah</b>	60
<b>8.0 Ah</b>	80

**Test setup:**

1) Step 2