



Einhell

EXPERT PLUS



Cordless Vacuum Cleaner

TE-VC 18 Li-Solo

Item No.: 2347120

Ident No.: 11028

Bar Code: 4006825612646

The Einhell TE-VC 18 Li-Solo cordless handheld vacuum cleaner is a convenient powerhouse from Power X-Change family. The same rechargeable battery can be used in all PXC devices. Every surface and crevice can be thoroughly cleaned thanks to the individual nozzles. The floor nozzle is suitable for smooth surfaces. A second nozzle is provided for upholstery and fabrics. Hard-to-reach areas can be cleaned effortlessly using the crevice nozzle. Use the 46.5 cm extension tube when you want to clean the floor using the handheld vac as a floor vacuum cleaner. The dust container has a capacity of 540 ml. For space-saving storage there is an integrated wall holder. The product is supplied without a battery & charger which are available separately.

Features & Benefits

- A member of the Power X-Change family
- Dust container with a volume of 540 ml
- Cleaning the filters under running water
- Incl. floor tool for hard floors and smooth surfaces
- Incl. crevice tool for hard to reach areas
- Incl. upholstery tool for cleaning upholstery and fabrics
- Incl. extension tube (46.5 cm) for cleaning floors
- Space-saving storage thanks to the integrated wall bracket
- Supplied without battery and charger (available separately)



Technical Data

- Suction power max. 42 mbar
- Volume 0.54 L

Logistic Data

- Product weight 0.95
- Dimensions single packaging 475 x 135 x 190 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 8.2 kg
- Dimensions Export Carton 490 x 290 x 410 mm
- Container quantity (20"/40"/40"HC) 1920 | 4000 | 4700



Available as special accessories



18V 1,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 30min Power-X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory